ENDON® Cordero Pendant Light Fitting

INSTRUCTION MANUAL

Safety Warnings

- This product is only suitable for connection to a 240V~50Hz supply in accordance with current IEE wiring
 regulations, and should be installed in accordance with local Building Regulations. They are for domestic, indoor
 ceiling use only, and are <u>not</u> suitable for a Bathroom location.
- The light fitting should be connected to a lighting circuit protected by a 5 amp fuse (or a 6 amp miniature circuit breaker).
- Before installing your light fitting always switch off the mains supply, and remove the appropriate fuse or switch off the appropriate circuit breaker before commencing installation. Ensure that no one else has access that would enable the supply to be inadvertently reconnected.
- This is a Class 1 product and must be Earthed. The terminal blocks are supplied according to requirements of the fitting.
- Never fit bulbs of a higher wattage than those specified on the label, as these may cause overheating and damage the fitting.
- This product is suitable for dimming when used with dimmable bulbs.
- If you are in any doubt about your competence please consult a qualified electrician.
- If any modification is made it will invalidate the warranty and may render the product unsafe.

Care Information

Allow 10 minutes to cool before replacing, adjusting or cleaning. Clean with a dry cloth only. Do not use liquid or abrasive cleaners on this product.

Assembly/ User Instructions

Before you start

Please read these instructions carefully before fitting and retain for reference.

Check the packaging and make sure that you have all the required parts. Follow each assembly step in order to prevent incorrect assembly. Ensure that the product is fully assembled as illustrated before use.

The Light pack contains:

Light fitting. Fixing pack. The following tools may be required:

Selection of cross and flat head screwdrivers. Electric drill and assorted drill bits. Wire strippers.

These assembly diagrams overleaf are intended as a guide – if in doubt consult a qualified electrician.

- 1. Decide on the position of the light fitting / or remove existing light fitting. Take a note of the position of the electrical connections. Ensure there is a solid mounting surface, preferably a wooden joist or joist bridge to support the weight of the light fitting.
- 2. Remove the two side screws (A) and retain for re-use. Use the fixing bracket (B) as a template to mark the screw holes. Make the screw holes and secure to the ceiling with appropriate fixings (C).
- <u>Height adjustment:</u> The height of this product can be reduced by pulling the cable through the cable grip (D) and removing chain links. Unscrew the carabiner (E) on the bottom chain link and remove unwanted links before retightening it. Always ensure the weight of the product is supported by the chain and not the cable.
- 4. Support your fitting and connect the house wiring to the terminal blocks (F) see expanded wiring details below. **NOTE: This is a Class I product and must be earthed.**
- 5. Re-fit the product to the fixing bracket using side screws, tighten to secure. Take care to avoid damaging any concealed wiring and pipes. Do not overtighten.



Endon Lighting, LS9 0SE

81969-Cordero-P 20190829

- 6. Fit the bulbs (G) not supplied). **NOTE: Never fit bulbs of a higher wattage than those specified on the label, as these may cause overheating and damage the fitting.**
- 7. Place the diffuser (H) inside the bottom of the shade and secure in place with the washer (I) and finial (J).
- 8. Turn on the power and test.

