







LUTEC





Timer




Sensor




Lux



Activate sensor override mode



De-activate sensor override mode



LUTEC Europe NV

Ruiterijschool 14
B-2930 Brasschaat - Belgium
+32 3 284 51 62
info@luteceurope.com
www.lutec.com



Lutec UK (for UK and Ireland) sales@lutecuk.com +44 (0)1992 760870
www.lutec.com/services/global-network