Touch Table Light

INSTRUCTION MANUAL

Safety Warnings


- This product is only suitable for connection to a 240V~50Hz supply in accordance with current IEE Wiring Regulations. It is for indoor use only, and not suitable for a bathroom location.
- This is a Class II, Double Insulated product and must not be earthed.
- Do not plug into the mains until your lamp is fully assembled.
- Under no circumstances must this table lamp be covered with any material as this could pose a safety hazard. It must be used on a stable, flat surface.
- This product is not suitable for persons under 14 years of age.
- Never fit bulbs of a higher wattage than those specified on the label (as these may cause overheating and damage the fitting)
- If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person. .
- If you are in any doubt about your competence please consult a qualified electrician.
- If any modification is made it will invalidate the warranty and may render the product unsafe.

Care Information

Allow 10 minutes to cool before adjusting or cleaning.

Clean with a dry cloth only. Do not use liquid or abrasive cleaners on this product.

Assembly/ User Instructions



Before you start

Please read these instructions carefully before fitting and retain for reference. Check the packaging and make sure that you have all the required parts. Follow each assembly step in order to prevent incorrect assembly. Ensure that the product is fully assembled as illustrated before use.

These assembly diagrams are intended as a guide—If in doubt, please consult a qualified electrician.

- 1. Carefully unpack your lamp, and place your lamp on a stable, flat surface.
- 2. Fit the bulbs (A not supplied). NOTE: Never fit bulbs of a higher wattage than those specified on the label (as these may cause overheating and damage the fitting).
- 3. Screw the shades (B) onto the threaded lampholders (C) to secure in place. Do not overtighten.
- 4. Plug in the lamp. This product has an on/off touch dimmer: touch once to turn on and again to turn off

If your lamp will not illuminate, please check the relevant fuse in your fuse box. If unsuccessful please consult your retailer.

To use this item in Europe, the 3 pin adaptor can be removed by loosening the central screw and removing the adaptor to reveal the 2 pin Europe plug.



- **EN** Scan QR code for multi-language
- FR Scannez le code QR pour plusieurs langues
- Escanee el código QR para varios idiomas
- 🖭 Zeskanuj kod QR dla wielu języków
- © Scannen Sie den QR-Code nach mehreren Sprachen
- Scansiona il codice QR per multilingua

